



Cleaning the Magic Bullet

Everyone hates cleaning up, which is just one more reason the Magic Bullet is so great. You can make and cook fresh homemade spaghetti meat sauce (see recipe on Page 69) from scratch and only use one tall Bullet cup! Imagine delicious, piping hot pasta sauces, salsa, fresh soups and more, all prepared with no cutting boards, no pots and pans, just a single cup and blade to put in the dishwasher. It doesn't get any easier than that.



Always unplug the Magic Bullet when cleaning or assembling.

Washing Magic Bullet Attachments

It is so easy ... Just place any of the pieces (except for the **Power Base**) on top shelf of the dishwasher, or hand wash with warm soapy water and rinse.



Always make sure the gaskets are still inside after cleaning. The heat from some dishwashers can cause them to become loose and pop out.



Stubborn cleanup When you let ingredients dry in the Magic Bullet, or when you've melted cheese in the cups, make your cleanup a snap by filling the cup with soapy water and microwaving it for one minute. That will loosen the stuck ingredients and with a light scrub, you'll be all done.

Cleaning the Magic Bullet Power Base

For the most part the **Power Base** doesn't really get dirty, but if you neglect to twist the blade onto the cup tightly, liquids can leak out and get into the base and activator buttons. Here's how to clean it up.

Before you begin ... The most important thing is to UNPLUG the **Power Base**!

Then ... Use a damp rag to wipe down the inside and outside of the **Power Base**.

Sometimes the base gets so dirty ... that the little white sliders that activate the Magic Bullet get sticky. This can cause the motor to continue to spin even after you've released the cup. When this happens, start by UNPLUGGING the **Power Base**.

Then ... Double-check that you've UNPLUGGED the **Power Base**, and use a damp rag to soften up the gunk around the activators as you work the activator buttons up and down until they move freely again.



NEVER SUBMERGE THE POWER BASE IN WATER OR PLACE IT IN DISHWASHER



Never put your hands or utensils near the moving blade and never use your hands or utensils to press the activator buttons down while the Power Base is plugged in.

Magic Bullet Blender

When it's time to whip up big batches of foods like pancakes, milkshakes, or frozen drinks, the Magic Bullet Blender has all the power and capacity of those expensive, bulky blenders without taking up all that counter space. The **Blender Lid** has two pouring spouts, one for straining and one for pouring, and a pop-out top, so you can add ingredients as you blend. Plus, everything is dishwasher-safe (top rack only), so cleanup is fast and easy.

Assembling the Magic Bullet Blender




Just ... Twist the **Cross Blade** onto the bottom of the blender pitcher.

Then ... Place the blender on the Magic Bullet base.

Using the Magic Bullet Blender

The Magic Bullet Blender is just like regular blenders, without all the confusing buttons.



Simply ... Place the assembled **Blender** onto the Power Base.

Then ... Push down on the **Blender** and twist clockwise until the tabs lock under the lip of the **Power Base** (**Lock On** mode).

And ... Put on the **Blender Lid** and blend.



Never run the Magic Bullet for more than one minute at a time, as it can cause permanent damage to the motor. If the motor stops working, unplug the **Power Base** and let it cool for a few hours before attempting to use it again. Your Magic Bullet has an internal thermal breaker that shuts the unit off when it overheats. Letting the thermal breaker cool down should allow it to reset.

Magic Bullet Juicer

Now you can make freshly squeezed juice every day of the week, at home, without all of the added sugar found in many store-bought juices and without the mess and big production that comes with most traditional juicers. In the **Magic Bullet Juicer**, making delicious, nutritious fresh juices like orange or pineapple, and instant energy cocktails is a snap.

Assembling the Magic Bullet Juicer

First ... Twist the **Cross Blade** onto the bottom of the **Blender**.

Then ... Insert the **Extractor** down the center of the **Blender** making sure to line the three notches up with the three ribs on the inside of the **Blender**.

Next ... Place the lid onto the **Blender** and align either the straining pourer or regular pourer up to the spout. Make sure the lid is locked on, it holds the **Extractor** insert in place.

And then ... Place the **Blender** on the Magic Bullet base.



Using the Magic Bullet Juicer

Before you begin ... Select your juice ingredients, make sure they are sized to fit into the **Extractor** and place them within arms reach of your **Magic Bullet Juicer**.

When you're ready to start juicing ... Remove the pop-top from the lid of the **Blender**, place the assembled **Magic Bullet Juicer** onto the **Power Base**, press down and turn the **Blender** clockwise until it is running in hands-free **Lock On** mode. **To avoid jamming the blades, which can cause serious motor damage, make sure the motor is running BEFORE you add any ingredients into the juicer.**